Quick Start Guide

Discovery™ iQ Wall Oven

Models: DYO130, DYO230, DYOV130 and DYOV230

Thank you for purchasing the Dacor Discovery™ iQ wall oven. In order for you to get the most from your oven and to take advantage of the Android operating system's capabilities, we want to ensure that your oven has been properly set up and connected to your wireless network.

These steps will help guide you through that process. Since there are many potential screens that might be displayed on your oven after installation, we have described what actions to take based on each screen. Of course, if you have any problems, please contact the Dacor Customer Service Team at (800) 793-0093.

Instructions:

WARNING - This appliance must be installed and grounded according to the included installation instructions prior to use.

STEP 1 When power to the oven is turned on for the first time, the setup program will run. It begins with WiFi setup. If the WiFi setup screen appears on the touch display, skip to step 8 of this guide. If the oven home screen appears, go to step 6 of this guide to restart the setup process. If any other screen appears on the display, go to step 2, on the following page, to restart the setup process.


Oven Setup: Wi-Fi
Select the wireless network you wish to join, then press Next. If you don't see the network you want to join, press Rescan.
Our Network
dacorworld
N Router
Rescan
Skip
Next

WiFi Setup Screen - Text in gray area will vary. Go to step 8.

Oven Home Screen, Double Oven - Go to step 6.

Oven Home Screen, Single Oven - Go to step 6.

STEP 2 Select the screen that currently appears on the touch display from the pictures shown. Perform the instructions below the picture to perform the setup restart process.

WiFi keyboard - Touch cancel, go to step 8.


Oven Setup: Wi-Fi
Select the wireless network you wish to join, then press Next. If you don't see the network you want to join, press Rescan.
Our Network
A new update was found. Would you like to update now?
Yes
No
Rescan
Skip
Next

Upgrade Screen - Touch No, go to step 8.



Privacy Policy - Touch box, Next, then go to step 4.


Oven Setup: User Profile
End User License Agreement
Dacor, Inc. End-User License Agreement
1. Scope of License.
Serial #: V-A-12345678
Model #: DYO230S
I have read and accept the End User License Agreement
Next

EULA - Touch box, Next, then go to step 5.


Oven Setup: User Profile
Please enter these required fields to continue the oven setup. Your personal info will only be used to improve your service experience.
First:
Last:
E-mail:
Yes, Dacor has permission to email me for support and service.
Skip
Next

Name Screen - Go to step 5.



Address Screen - Go to step 5.



Profile keyboard - Go to step 5.


Oven Setup: Complete
Congratulations!
You have successfully setup your user profile. You can now begin using your Discovery IQ™ Wall Oven. Please select next to launch the tutorial wizard or select skip to launch the Dacor IQ Cooking Application. Don't forget to complete and mail your Warranty Registration Card or click here to visit the Warranty Registration Page on dacor.com
Skip
Next

Congratulations Screen - Go to step 5.

STEP 3 On the *Privacy Policy* screen, touch the check box at the bottom left. Touch **Next**.


Oven Setup: User Profile
Privacy Policy
Collection of Personally Identifiable Information
We collect the email addresses of those who communicate with us via email, aggregate information on what pages consumers access or visit, information volunteered by the consumer, such as survey information and/or site registrations, name and address, telephone number, fax number, and email address.
The information we collect is used to improve the content of our Web page, customize the content and/or layout of our page for each individual visitor, notify consumers about updates to our Website, shared with other reputable organizations to help them contact consumers for marketing purposes, used by us to contact consumers for marketing purposes.
Cookies
We use cookies to store visitors' preferences, record session information, such as items that consumers add to their shopping cart.
I have read and accept the Dacor Privacy Policy
Next

STEP 4 On the *End User License Agreement* screen, touch the check box at the bottom left. Touch **Next**.


Oven Setup: User Profile
End User License Agreement
Dacor, Inc. End-User License Agreement
PLEASE READ CAREFULLY THE TERMS AND CONDITIONS OF THIS END USER LICENSE AGREEMENT (THE EULA or AGREEMENT) BEFORE DOWNLOADING, INSTALLING OR USING ANY SOFTWARE PROVIDED BY DACOR, INC. (DACOR OR WE) OR ENABLING ANY SUCH APPLICATION (COLLECTIVELY, THE LICENSED APPLICATION). THIS IS A LEGAL AGREEMENT BETWEEN DACOR AND YOU. THIS EULA AND THE DACOR PRIVACY POLICY (AVAILABLE AT HTTP://WWW.DACOR.COM) ALL OF WHICH ARE INCORPORATED HEREIN BY REFERENCE (AND COLLECTIVELY REFERRED TO HEREUNDER AS THE EULA), GOVERN YOUR ACCESS TO AND USE OF THE DACOR APPLICATION. In the event there is a contradiction between this EULA and the Dacor Mobile Privacy Policy, the Dacor Privacy Policy will control.
1. Scope of License.
This license granted to You for the Licensed Application by Dacor is limited to a non-transferable license to use the Licensed Application on any Dacor appliance that You own or control. You may not rent, lease, lend,
Serial #: V-A-12345678
Model #: DYO230S
I have read and accept the End User License Agreement
Next

STEP 5 Touch **Skip** on all of the following screens, until the oven home screen appears on the display.


Oven Setup: User Profile
Please enter these required fields to continue the oven setup. Your personal info will only be used to improve your service experience.
First:
Touch here to enter First Name...
Last:
Touch here to enter Last Name...
E-mail:
Touch here to enter E-mail...
Yes, Dacor has permission to email me for support and service.
Skip
Next

STEP 6 Touch **Oven Preferences** on the oven home screen.

Oven Home Screen - Double Oven shown.

GOEDEKER'S Trusted since 1951

STEP 7 The **Oven Preferences** menu will appear. Use the down (∨) arrow until **Oven Setup** appears on the display. Touch **Oven Setup**. It may take 30 to 60 seconds for all of the available wireless networks to appear on the display.



STEP 8 Touch to select your wireless network, then touch **Next**. If you do not have a wireless network, touch **Skip**.


Oven Setup: Wi-Fi
Select the wireless network you wish to join, then press Next. If you don't see the network you want to join, press Rescan.
Our Network
dacorworld
N Router
Rescan
Skip
Next

STEP 9 If the wireless network selected has a password, a keyboard will appear on the display. Touch the keys on the display to enter the password, then touch **Join**.

STEP 10 The oven will check for updates to the system software. If the "Would you like to update now?" prompt appears on the display, touch **Yes** and wait for the software to update. Follow the prompts on the display. After the update is completed, the display will return to the Wifi setup display (shown in step 8).


Oven Setup: Wi-Fi
Select the wireless network you wish to join, then press Next. If you don't see the network you want to join, press Rescan.
Our Network
A new update was found. Would you like to update now?
Yes
No
Rescan
Skip
Next

STEP 11 Touch **Next**.

STEP 12 Read the *Privacy Policy* screen, then touch the check box at the bottom left, then touch **Next**.


Oven Setup: User Profile
Privacy Policy
Collection of Personally Identifiable Information
We collect the email addresses of those who communicate with us via email, aggregate information on what pages consumers access or visit, information volunteered by the consumer, such as survey information and/or site registrations, name and address, telephone number, fax number, and email address.
The information we collect is used to improve the content of our Web page, customize the content and/or layout of our page for each individual visitor, notify consumers about updates to our Website, shared with other reputable organizations to help them contact consumers for marketing purposes, used by us to contact consumers for marketing purposes.
Cookies
We use cookies to store visitors' preferences, record session information, such as items that consumers add to their shopping cart.
I have read and accept the Dacor Privacy Policy
Next

STEP 13 Read the *End User License Agreement* screen, then touch the check box at the bottom left, then touch **Next**.


Oven Setup: User Profile
End User License Agreement
Dacor, Inc. End-User License Agreement
PLEASE READ CAREFULLY THE TERMS AND CONDITIONS OF THIS END USER LICENSE AGREEMENT (THE EULA or AGREEMENT) BEFORE DOWNLOADING, INSTALLING OR USING ANY SOFTWARE PROVIDED BY DACOR, INC. (DACOR, OR WE) OR ENABLING ANY SUCH APPLICATION (COLLECTIVELY, THE LICENSED APPLICATION). THIS IS A LEGAL AGREEMENT BETWEEN DACOR AND YOU. THIS EULA AND THE DACOR PRIVACY POLICY (AVAILABLE AT HTTP://WWW.DACOR.COM), ALL OF WHICH ARE INCORPORATED HEREIN BY REFERENCE (AND COLLECTIVELY REFERRED TO HEREUNDER AS THE EULA), GOVERN YOUR ACCESS TO AND USE OF THE DACOR APPLICATION. In the event there is a contradiction between this EULA and the Dacor Mobile Privacy Policy, the Dacor Privacy Policy will control.
1. Scope of License.
This license granted to You for the Licensed Application by Dacor is limited to a non-transferable license to use the Licensed Application on any Dacor Appliance that You own or control. You may not rent, lease, lend,
Serial #: V-A-12345678
Model #: DYO230S
I have read and accept the End User License Agreement
Next

STEP 14 Touch the gray area next to **First** on the name screen.


Oven Setup: User Profile
Please enter these required fields to continue the oven setup. Your personal info will only be used to improve your service experience.
First:
Touch here to enter First Name
Last:
Touch here to enter Last Name
E-mail:
Touch here to enter E-mail...
Yes, Dacor has permission to email me for support and service.
Skip
Next

STEP 15 The keyboard screen will appear. Enter your first name using the keys on the screen, then touch **Save**.

STEP 16 Repeat steps 14 and 15 for your last name and E-mail sections on the name screen, then touch **Next**. Note: E-mail address is optional.



GOEDEKER Trusted since 1951

STEP 17 Touch the gray area next to **Address** on the address screen.



STEP 18 Enter your address using the keys on the keyboard screen, then touch **Save**.

STEP 19 Repeat steps 17 and 18 for your remaining sections on the address screen, then touch **Next**.



STEP 20 When the Congratulations screen appears, Dacor recommends that you touch **Click here** to register the warranty for your oven.

STEP 21 Touch **Next**. Oven setup is complete.


Oven Setup: Complete
Congratulations!
You have successfully setup your user profile. You can now begin using your Discovery IQ™ Wall Oven. Please select next to launch the tutorial wizard or select skip to launch the Dacor IQ Cooking Application. Don't forget to complete and mail your Warranty Registration Card or click here to visit the Warranty Registration Page on dacor.com
Skip
Next

GOEDEKER'S
Trusted since 1951

GOEDEKER'S
Trusted since 1951

Dacor.com

Dacor ● 14425 Clark Avenue, City of Industry, CA 91745 ● Phone: (800) 793-0093 ● Fax: (626) 403-3130 ● www.dacor.com